

- Valve body 1.1 Nuts
- 1.2 Gasket

2 3

- Seat Plug
- 4.1 Spring
- 4.2 Packing
 - Valve bonnet
- 5.2 Threaded bushing
- 5.3 Travel indicator scale Plug stem

6.3 Yoke

- 6.1 Stem connector nut 6.2 Lock nut
 - (DN 200 and 250) Stem connector
- Actuator 8.1 Actuator stem
- 8.2 Nut